

## Fuse Replacement

The fuse holder is by the battery.

The specified fuse is 10A.

When frequent fuse failure occurs, it usually indicates a short circuit or an overload in the electrical system. See your authorized Honda dealer for repair.

### **WARNING**

- \* *Never use a fuse with a different rating from that specified. Serious damage to the electrical system or a fire may result, causing a dangerous loss of lights or engine power at night or in traffic.*

### **CAUTION:**

- \* *Turn the ignition switch OFF before checking or replacing the fuse to prevent accidental short-circuiting.*