

CAUTION:

- * *Do not shift gears without disengaging the clutch and closing the throttle. The engine and drive train could be damaged by overspeed and shock.*
- * *Do not tow the motorcycle or coast for long distances while the engine is off. The transmission will not be properly lubricated and damage may result.*
- * *Do not exceed 8,000 rpm when running the engine without a load. Serious engine damage may result.*

NOTE:

- * The battery will not charge while the engine speed is below 1,750 rpm. Avoid idling for prolonged periods, or continuous operation below 1,750 rpm.
- * Be careful when revving the engine or accelerating in 1st or 2nd gear as the engine speed will easily enter the tachometer red zone.

High Altitude Riding

When operating this motorcycle at high altitude, the air-fuel mixture becomes overly rich. Above 6,500 feet (2,000 m) driveability and performance may be reduced and fuel consumption increased. See your authorized Honda dealer for high altitude adjustments.