

(Ref. No.) Description	Function
(1) Speedometer	Shows riding speed.
(2) Odometer	Shows accumulated mileage.
(3) Left turn signal indicator (green)	Flashes when the left turn signal operates.
(4) Tachometer	Shows engine rpm.
(5) Tachometer red zone	Never allow the tachometer needle to enter the red zone, even after the engine has been broken in. CAUTION: * Running the engine beyond recommended maximum engine speed (tachometer red zone) can damage the engine.
(6) Right turn signal indicator (green)	Flashes when the right turn signal operates.
(7) Coolant temperature gauge	Shows coolant temperature (see page 12).
(8) Side stand indicator (amber)	Lights when the side stand is put down. Before parking, check that the side stand is fully down; the light only indicates the side stand ignition cut-off system (page 54) is activated.