

### **Front and Rear Suspension Inspection**

1. Check the front fork assembly by locking the front brake and pumping the forks up and down vigorously. Suspension action should be smooth and there must be no oil seepage.
2. Check for play in the swingarm by moving the rear wheel sideways.
3. Carefully inspect all front and rear suspension fasteners for tightness.

### **SIDE STAND**

Check the side stand spring for damage and loss of tension, and the side stand assembly for freedom of movement.

If the side stand is squeaky or stiff, clean the pivot area and lubricate the pivot bolt with engine oil.