



**To install the sensor:**

- Turn the front wheel so one of the poles of the pulser ring and sensor face each other.
- Insert a feeler gauge 0.5 mm furnished in the tool kit between the sensor and pole, then hold the sensor lightly against the pole.
- Tighten the sensor mounting bolt securely.

Specified torque:  
**12 N·m (1.2 kgf-m, 9 lbf-ft)**

- Remove the feeler gauge.
- Rotate the front wheel one full turn to make sure that the pulser ring does not interfere with the sensor.

