

## FUEL TANK

### Fuel Fill Cap

The fuel fill cap (Fig. 2-22) has a fuel cap vent lever (2) with ON and OFF positions. The lever should be turned to ON to allow fuel to flow when running the engine. Turn the vent lever to OFF to prevent fuel from flowing out the vent hole when transporting the FOURTRAX.




Fig. 2-22 (1) Fuel fill cap

(2) Fuel cap vent lever