

## **DIFFERENTIAL OIL**

Change the oil in the differential when specified by the Maintenance schedule. Change the oil with the differential warm, and the FOURTRAX on level ground to assure complete and rapid draining.

To change the differential oil:

1. To drain the oil, first place an oil drain pan under the oil drain plug (Fig. 4-15).
2. Remove the oil filler cap ( 1) and the drain plug ( 2).
3. After the oil has completely drained, reinstall the drain plug.  
Drain Plug Torque:  
9 lbf·ft (12 N·m , 1.2 kgf·m)
4. Fill the differential with the recommended oil.

Differential oil:

6.4 US oz (190 cm<sup>3</sup> , 6.7 Imp oz)

Recommended oil:

Honda shaft drive oil or equivalent HYPOID GEAR OIL SAE 80

Make sure the oil level reaches the lower edge of the inspection hole ( 3).

5. Install the oil filler cap.