

# Starting & Stopping the Engine

---

## High Air Temperature 35°C (95°F) or above

1. Do not use the choke.
2. With the throttle closed, start the engine.

## Low Air Temperature 10°C (50°F) or below

1. Pull the choke lever ( 1 ) up all the way to fully ON (A) if the engine is cold.
2. With the throttle 1/8 – 1/4 open, start the engine.
3. Warm up the engine by opening and closing the throttle slightly.
4. Continue warming up the engine until it runs smoothly and responds to the throttle, when the choke lever down all the way to fully OFF.
5. If idling is unstable, open the throttle slightly.

### **NOTICE**

*Extended use of the choke may impair piston and cylinder wall lubrication and shorten the life of the engine.*