
## **Operating Controls**



The three-way fuel valve is used to control the flow of fuel from the fuel tank to the carburetor.

## ON

Turning the fuel valve ON before attempting to start the engine allows fuel to flow from the fuel tank to the carburetor.

## **OFF**

Turning the fuel valve OFF after stopping the engine prevents the flow of fuel from the fuel tank to the carburetor.

## RES

Turning the fuel valve to RES allows fuel to flow from the reserve fuel supply to the carburetor.