

6. ALTERNATOR

SERVICE INFORMATION	6-1
ALTERNATOR REMOVAL	6-2
ALTERNATOR INSTALLATION	6-3

SERVICE INFORMATION

GENERAL

- This section covers removal and installation of the alternator. These operations can be done with the engine installed after removing the left crankcase cover.
- For alternator inspection and troubleshooting, refer to section 15.

TORQUE VALUE

Rotor nut 65–75 N·m (6.5–7.5 kg·m, 47–54 ft·lb)

TOOLS

Common

Rotor puller 07733–0010000 or 07933–0010000
Universal holder 07725–0030000