
## **Checking the Clutch**

## Checking the Clutch Lever Freeplay

Check the clutch lever freeplay.

## Freeplay at the clutch lever:

3/8 - 13/16 in (10 - 20 mm)



Check the clutch cable for kinks or signs of wear. If necessary have it replaced by your dealer.

Lubricate the clutch cable with a commercially available cable lubricant to prevent premature wear and corrosion.

## NOTICE

Improper freeplay adjustment can cause premature clutch wear.