



Spark Plug u Checking Spark Plug

1. Disconnect the spark plug cap from the spark plug.
2. Clean any dirt from around the spark plug base.
3. Remove the spark plug using a suitable spark plug wrench.



4. Inspect the electrodes and center porcelain for deposits, erosion or carbon fouling.
 - u If the erosion or deposit is heavy, replace the plug.
5. Make sure that a 1.0 mm wire-type feeler gauge cannot be inserted between the spark plug gap. If the gauge fits in the gap, replace the plug with a new one.



6. Make sure the plug washer is in good condition.