## **Instruments** (Continued)

## Initialize

You can calibrate of the touch screen.



- 1 Select [Initialize], and then press the ENT switch.
- 2 Select [Touchscreen Calibration], and then press the **ENT** switch.

