



Ignition switch


Switches the electrical system on/off, locks the steering.

Make sure that the Honda SMART Key is activated  P.56


and enter the operating range.  P.57




(Lock)




OFF







ON



ACC



  : Turning the ignition switch clockwise.

  : Turning the ignition switch counterclockwise.