

## Tire Puncture ► Removing Wheels

- Loosen the rear axle nut, lock nuts and turn the adjusting bolts so the rear wheel can be moved all the way forward for maximum drive chain slack.
- Remove the drive chain from the rear wheel sprocket by pushing the rear wheel forward.
- Remove the rear axle nut and washer.
- Remove the rear axle shaft, brake caliper bracket, rear wheel and side collars.
  - Support the brake caliper assembly so that it doesn't hang from the brake hose. Do not twist the brake hose.
  - Avoid getting grease, oil, or dirt on the disc to pad surfaces.
  - Do not push the brake pedal while the wheel is removed.
  - Do not pull the parking brake lever while the wheel is removed.

