


Starting & Stopping the Engine

Always follow the proper starting procedure described below.

For your safety, avoid starting or operating the engine in an enclosed area such as a garage. Your ATV's exhaust contains poisonous carbon monoxide gas which can collect rapidly in an enclosed area and cause illness or death.

Preparation



- (1) fuel valve (3) neutral indicator
(2) ignition switch (4) engine stop switch

1. Before starting, select a level surface and lock the parking brake ([page 40](#)).
2. Turn the fuel valve (1) and ignition switch (2) to ON (q).

Confirm the following:

- The transmission is in neutral, and the neutral indicator (3) is ON.
- The engine stop switch (4) is set to RUN (e).