

## Engine Oil u Changing Engine Oil, Cleaning Strainer Screen

3. Place your scooter on its center stand on a firm, level surface.
4. Place a drain pan under the drain bolt and oil plug.
5. Remove the oil fill cap/dipstick, drain bolt and sealing washer to drain the oil.
6. Remove the oil plug, O-ring, spring, and oil strainer screen and let the remaining oil drain out.
  - u Discard the oil at an approved recycling center.
7. Clean the oil strainer screen.
8. Check that the oil strainer screen and sealing rubber are in good condition.
9. Replace the O-ring and apply a thin coat of engine oil to the new O-ring before installing it.
10. Install the oil strainer screen, spring and oil plug and tighten.

**Torque:** 15 lbf·ft (20 N·m, 2.0 kgf·m).

