Flooded Engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. To clear a flooded engine.

- 1. Leave the engine stop switch set to (RUN).
- 2. Push the choke lever in all the way to fully OFF.
- 3. Open the throttle fully.
- 4. Press the start button for 5 seconds.
- If the engine starts, quickly close the throttle, then open it slightly if idling is unstable.

If the engine does not start, wait 10 seconds, then follow the High Air Temperature procedure (page 46).

RUNNING-IN

Help assure your motorcycle's future reliability and performance by paying extra attention to how you ride during the first 500 km (300 miles).

During this period, avoid full-throttle starts and rapid acceleration.