

Oil filter change:

Change the filter after draining the engine oil.

1. Remove the oil filter element from the cover.
2. Check that the O-rings on the oil filter bolt and cover are in good condition.
3. Insert a new oil filter element. Check that all parts are installed properly. Install the oil filter cover.
Oil filter bolt torque: 28–32 N·m (2.8–3.2 kg·m, 20–23 ft·lb)
4. Perform steps 4–7 of Oil Change.

Reemplazo del filtro de aceite:

Reemplace el filtro por uno nuevo después de drenar el aceite de motor.

1. Desmonte el elemento del filtro de aceite de la cubierta.
2. Revise que los anillos O del tornillo del filtro de aceite y los de la cubierta estén en buen estado.
3. Introduzca un nuevo elemento del filtro de aceite. Revise que todas las piezas estén correctamente montadas. Monte la cubierta del filtro de aceite.
Torsión de aprieto del tornillo del filtro de aceite: 28–32 N·m (2,8–3,2 kg·m)
4. Lleve cabo los trabajos indicados en los pasos 4–7 de la sección concerniente al Cambio de aceite.