

3. Tighten the rear axle nut and secure the nut with a new cotter pin.

**Rear axle nut torque:**

**70–100 N·m (7.0–10.0 kg-m) [51–72 ft-lb]**

4. Tighten the lock nuts.
5. Check drive chain slack.
6. Rear brake pedal free play is affected when repositioning the rear wheel to adjust drive chain slack. Check rear brake pedal free play and adjust as necessary (page 106).

**CAUTION: Always replace used cotter pins with new ones.**

- 
3. Apriete la tuerca del eje trasero y fijela con una nueva clavija hendida.

**Torsión de aprieto para la tuerca del eje trasero:**

**70–100 N·m (7,0–10,0 kg-m)**

4. Apriete las contratuercas.
5. Revise la flojedad de la cadena de transmisión.
6. Al reponer la rueda trasera para ajustar la flojedad de la cadena de transmisión, el juego libre del pedal del freno trasero será afectado. Revise el juego libre del pedal de freno trasero y ajústelo si necesario. (página 106).

**PRECAUCION: Siempre reemplace las clavijas hendidas usadas por unas nuevas.**