


## Steering Lock (General type)

The steering can be locked when the ignition switch (1) is in "LOCK" position.

Turn the handlebar all the way to the steering stop, either to the left or right, insert the key at the "OFF" position turn it counterclockwise to "LOCK" position while pushing in and then remove the key. To unlock, only turn the key clockwise.



## Bloqueador del Manubrio (Tipo general)

El manubrio puede bloquearse cuando el interruptor del encendido (1) esté colocado en la posición "LOCK".

Gire el manubrio completamente a la izquierda o a la derecha hasta el fin de su curso, inserte la llave en la posición "OFF", gírela en el sentido inverso de las manecillas de un reloj hasta la posición "LOCK" mientras que se la empuje adentro, luego, retire la llave. Para desbloquear el manubrio, gire la llave en el sentido del movimiento de las manecillas de un reloj simplemente.