

Ignition Switch


The ignition switch is located directly below the indicator panel.

OFF: All electric circuits open. Engine cannot be started. Key can be removed. G: Key cannot be removed.

ON: All electric circuits closed. Engine and light can be operated. Key cannot be removed.

P (PARKING): All electric circuits open except for taillight and position light. Key can be removed.

LOCK (STEERING LOCK): See page 78.



Commutateur d'allumage

Le commutateur d'allumage se trouve directement sous le tableau d'indicateurs.

OFF: Tous les circuits électriques sont ouverts. Le moteur ne peut pas démarrer. La clé peut être retirée.

ON: Tous les circuits électriques sont fermés. Le moteur et les feux peuvent fonctionner. La clé ne peut pas être retirée.

P (PARKING): Tous les circuits électriques sont ouverts, sauf ceux pour le feu arrière et le feu de position. La clé peut être retirée.

LOCK (VERROUILLAGE DU GUIDON): Voir page 78.