

## CONTROL FUNCTION FONCTION DES COMMANDES

### Choke Lever

When the engine is cold, push the choke lever ① down. After the engine has warmed up, slowly return the choke to the fully opened position. When the engine is warm it is possible to start the engine with the choke in a fully open position.

Do not leave the choke in the closed position, after the engine is warmed-up.

#### WARNING

For safety, do not operate the choke lever while driving.

### Levier du volet d'air

Quand le moteur est froid, poussez le levier du volet d'air ① vers le bas. Une fois que le moteur est réchauffé, retourner lentement le volet d'air à la position d'ouverture maximale. Lorsque le moteur est chaud on peut faire démarrer le moteur avec le volet d'air à la position d'ouverture maximale.

Ne pas laisser le volet d'air à la position fermée une fois que le moteur est réchauffé.

#### AVERTISSEMENT

Pour plus de sécurité, ne pas utiliser le levier du volet d'air au cours de la conduite.

