

# MAINTENANCE OPERATIONS TRAVAUX D'ENTRETIEN

Place the ODYSSEY on a level surface.

## **WARNING**

- Take care not to touch the hot parts.

### Carburetor adjustment

Idle speed has been adjusted at 1,500 rpm on delivery from factory.

All carburetor adjustments should be made only by an authorized Honda ODYSSEY dealer.

## **WARNING**

- The belt converter engages at engine speeds above 3,500 rpm and the ODYSSEY will begin to move. Do not approach this engine speed when performing maintenance operations or adjustments unless the rear tires are raised off the ground.

Placer l'ODYSSEY sur une surface nivelée.

## **AVERTISSEMENT**

- Veiller à ne pas toucher les pièces chaudes.

### Réglage du carburateur

Le régime de ralenti a été réglé à 1,500 t/m avant la sortie d'usine.

Tous les réglages de carburateur doivent être effectués seulement par un concessionnaire autorisé Honda ODYSSEY.

## **AVERTISSEMENT**

- Le convertisseur de la courroie entre en fonction à des vitesses de moteur au-dessus de 3,500 t/m et à ce moment l'ODYSSEY commencera à bouger. Ne pas atteindre cette vitesse du moteur au cours de l'exécution des travaux ou de réglages d'entretien à moins que les pneus arrière ne soient soulevés du sol.

