

Air cleaner maintenance

The air cleaner element must be cleaned and oiled at least once 3 months. If your ODYSSEY is operated in dusty areas, more frequent servicing will be required. Your Honda dealer can help you to determine the correct service interval for your particular riding conditions.

1. Remove the wing bolts ①, and remove the air cleaner case cover ②.
2. Remove the air cleaner element ③ by removing a 6mm bolt.
3. Wash the element in clean nonflammable or high flash point solvent and dry it thoroughly.

Entretien du filtre à air

L'élément de filtre à air doit être nettoyé et huilé une fois tous les trois mois au moins. Si vous utilisez votre ODYSSEY dans des endroits poussiéreux, un entretien à intervalles plus rapprochés sera requis. Votre concessionnaire Honda est en mesure de vous aider à déterminer les intervalles d'entretien appropriés selon vos conditions particulières de conduite.

1. Enlever les boulons ailés ①, et enlever le couvercle du filtre à air ②.
2. Enlever l'élément de filtre à air ③ en déposant le boulon de 6mm.
3. Laver l'élément dans un solvant non inflammable ou à point d'éclair élevé.

