

Throttle cable maintenance

With the throttle lever ① squeezed, check the free movement ② of the throttle outer cable ③ at the carbretor side is approximately 1 mm (0.04 in).

If not, slide off the rubber cap ④ and turn the cable holder ⑤ in or out as required.

After adjusting, replace the rubber cap to its original position.

Entretien du câble des gaz

Serrer le levier de commande des gaz ①, et s'assurer que le mouvement libre ② du câble extérieur de commande des gaz ③ au niveau du carburateur est d'environ 1 mm (0,04 po).

Si ce n'est pas le cas, retirer le capuchon en caoutchouc ④ et tourner le tendeur ⑤ dans l'un ou l'autre sens selon le besoin.

Après le réglage, remettre le capuchon en caoutchouc sur sa position initiale.

