

5. After taking the belt ② out of the driven pulley remove from the drive pulley.
6. Reverse the procedure to install the new belt.

**NOTE:**

When the pulley does not turn smoothly, move the vehicle in the direction of pulley rotation.

**⚠ WARNING**

- Check the drive belt often. If there is excessive wear, burns from slippage, or cracks it should be replaced immediately.
- Always carry a spare belt (optional).

5. Après avoir retiré la courroie ② de la poulie menée, déposer la pulie menante.
6. Inverser ce processus pour installer la nouvelle courroie.

**REMARQUE:**

Si la poulie ne tourne pas avec facilité, déplacer le véhicule dans la direction de rotation de la poulie.

**⚠ AVERTISSEMENT**

- Vérifier souvent la courroie d'entraînement. En cas d'usure excessive, de brûlures causées par patinage ou de fissures, il faut la remplacer immédiatement.
- Il faut toujours avoir à disposition une courroie de rechange (en option).

