Switches *(Continued)*

ENT switch
Press to set your selection. P.37

▲ Sel up switch
Press the sel up switch to select the available choices. P.37

◀ ▶ Sel left/right switch
Press the ◀ ▶ sel left/right switch in the ◀ / ▶
directions to select the available choices. P.37

◀◀ Goes back switch
Goes back to the beginning of the current or previous
song or to move rapidly within a track. P.173

↩ Back switch
Press to return to the previous screen.
P.38

▶▶ Skip switch
Skips to the next song or to move rapidly
within a track. P.173

▼ Sel down switch
Press the sel down switch to select the available choices. P.37