Maintenance Component Locations

choke knob

rear brake
lever/parking
brake lever

front brake fluid reservoir

front brake lever

throttle lever

fuel fill cap