PGM-FI MALFUNCTION INDICATOR 33 BLINKS (E^2-PROM)

Turn the ignition switch OFF.

Disconnect the ECM connectors.
Check for loose or poor contact of the ECM connectors.



Connect the ECM connectors.
Short the service check connector with a jumper wire (page 5-6).
Turn the ignition switch ON and check the malfunction indicator blinks.

33 blinks → Reset the self-diagnosis memory data (page 5-7).
Turn the ignition switch ON and check the malfunction indicator blinks.

33 blinks → • Replace the ECM

Blinks → Remove the jumper wire from the service check connector (page 5-7).



Except 33 blinks

Turn the ignition switch ON and check the malfunction indicator blinks.

Except 33 blinks → • No problem

33 blinks