

Insert the *cam chain guide* into cylinder and crankcase. Install it by aligning the its bosses with the grooves in the cylinder and crankcase securely.

Install the cylinder head (page 10-19).

