

2. Inspect the electrodes and center porcelain for deposits, erosion or carbon fouling. If the erosion or deposit is heavy, replace the plug. Clean a carbon or wet-fouled plug with a plug cleaner, otherwise use a wire brush.
3. Regap to 0.8 – 0.9 mm (0.032 – 0.036 in.) (1). Measure with a feeler gauge and adjust by bending the side electrode (2) only. Do not overtighten.

- 
2. Inspeccione los electrodos y partes en porcelana del centro para ver si haya depósitos, erosión o suciedad de carbón. Reemplace la bujía si está excesivamente corroída o manchada. Utilice una escoba de bujía para limpiar la bujía o un cepillo de alambre; luego, límpie en una solución y séquela.
  3. Reajuste la separación de los electrodos a 0,8–0,9 mm (0,032–0,036 in.). Mídala con un calibre de espesor y ajústela doblando el electrodo lateral (2) sólo. No apriete excesivamente.