

8. Screw out the head pipe knob ① until the height of the handle bar knobs ②.
9. Turn the stem nut ③ clockwise completely and tap the head pipe knob lightly.
10. Separate the front fork from the frame body.

Place the separated motorcycle components in the trunk and fix them firmly to protect them from interfering each other.

-
- ① Head pipe knob
 - ② Handle bar knobs
 - ③ Stem nut

