

## If You Have a Flat Tire

---

10. Reinstall the mufflers.
  - Before installing the muffler, replace the muffler gasket with a new gasket.Tighten the nuts and bolts to the specified torques:
  - exhaust pipe joint nut:  
18 lbf·ft (25 N·m , 2.5 kgf·m)
  - muffler bracket bolt:  
20 lbf·ft (27 N·m , 2.8 kgf·m)
  - muffler bracket nut:  
32 lbf·ft (44 N·m , 4.5 kgf·m)
11. Reinstall the right footpeg.
  - Tighten the nut and bolts to the specified torque:
    - footpeg bolt A, B and nut:  
29 lbf·ft (39 N·m , 4.0 kgf·m)

If a torque wrench was not used for installation, see your Honda dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capability.