

'85:

Install the brake caliper torque link onto the swing arm and tighten the castle nut.
Install a new cotter pin.

'85 AND AFTER '85:

Secure the brake hose and cable to the swing arm with the two bolts and clamps.
Connect the shock link and arm to the shock lower mount (Page 12-14).
Install the rear axle (Page 11-7) and wheels (Page 11-3).

