

Side Nets

Rear Side Nets Roll Up (SXS700M4/M4D only)

1. Release the side net buckle.
2. Unhook the side net snap hooks and slide the D-rings out of the stays.
3. Roll up the side net tightly, folding in the buckle and snap hooks on the way.
4. Hook the two upper side net hooks to the top edge of the side net.

Rear Side Nets Roll Down (SXS700M4/M4D only)

1. Unhook the upper side net hooks.
2. Hook the side net snap hooks and fasten the side net buckle.

Always return the side nets to their normal positions, properly fastened, and tightened before driving.

