

NOTE

- Using wires, hang the front brake master cylinder at least as high as the position it was originally installed to prevent air from getting into the master cylinder. Do not twist the brake hose.
- Route the cables and wire harnesses properly (page 1-21).
- After installing the handlebar, adjust-
 - the throttle cable
 - the clutch cable
 - the choke cable

Procedure		Q'ty	Remarks
	Removal Order		Installation is in the reverse order of removal.
(1)	Rearview mirror	2	
(2)	Clutch switch connector	2	
(3)	Clutch lever assembly	1	Align the holder end with the punch mark on the handlebar and face the holder "UP" mark upward. Tighten the upper bolt first, then the lower bolt.
(4)	Left handlebar switch housing screw	2	Tighten the front screw first, then the rear screw.
(5)	Left handlebar switch housing	1	
(6)	Choke cable	1	
(7)	Handlebar weight mounting screw	1	
(8)	Handlebar weight	1	
(9)	Handle grip	1	Apply Honda Bond A or an equivalent to the inside surface of the grip.
(10)	Brake light switch connector	2	
(11)	Master cylinder	1	Align the holder end with the punch mark on the handlebar and face the holder "UP" mark upward. Tighten the upper bolt first, then the lower bolt.
(12)	Right handlebar switch housing screw	2	Tighten the front screw first, then the rear screw.
(13)	Right handlebar switch housing	1	
(14)	Handlebar weight mounting screw	1	
(15)	Handlebar weight	1	
(16)	Cap	4	
(17)	Handlebar holder bolt	4	Tighten the front bolts first, then the rear bolts.
(18)	Handlebar holder	2	Install the upper holder with its punch mark facing forward.
(19)	Throttle cable end	2	
(20)	Throttle pipe	1	
(21)	Handlebar	1	Place the handlebar onto the lower holder and align the punch marks on the handlebar with the lower surface of the handlebar holder.