

Install choke lever to handlebars

Clean L. handle grip completely

Apply recommended "Honda Bonda A" or "Semedine #540" to grip internally and install making sure grip cannot turn

* After installing grip make sure it cannot turn

Install handle weight

Install choke cable to choke lever

Align L. switch case protrusion with handle hole and install

Tighten 2 screws

* Tighten front screws first then rear screws

Install clutch lever bracket and holder and tighten bolts

Torque : 0.7-1.1 Kg-m

* Align holder mark with handle punch mark
* Face holder "UP" mark upwards
* Tighten top bolt first then bottom bolt

