

Basic Operating Instructions

This section gives basic information on how to start and stop your engine as well as break-in guidelines.

Safe Riding Precautions.....	16
Starting & Stopping the Engine	17
Fast Idle Knob	17
Preparation	17
Starting Procedure	17
How to Stop the Engine.....	18
Break-in Guidelines	19