MAINTENANCE

page

61 MAINTENANCE

- 61 THE IMPORTANCE OF MAINTENANCE
- 62 MAINTENANCE SAFETY
- 63 SAFETY PRECAUTIONS
- 64 MAINTENANCE SCHEDULE
- 67 TOOL KIT
- 68 SERIAL NUMBERS
- 69 COLOUR LABEL
- 70 AIR CLEANER
- 71 CRANKCASE BREATHER
- 72 ENGINE OIL
- 76 SPARK PLUG
- 78 VALVE CLEARANCE
- 80 DRIVE CHAIN
- 87 FRONT AND REAR SUSPENSION INSPECTION
- 88 SIDE STAND
- 89 WHEEL REMOVAL
- 94 BRAKE PAD WEAR

page

- 95 BRAKE SHOE WEAR
- 96 BATTERY
- 98 FUSE REPLACEMENT
- 101 BRAKELIGHT SWITCH ADJUSTMENT
- 102 BULB REPLACEMENT
- **109 CLEANING**
- **112 STORAGE GUIDE**
- 112 STORAGE
- 114 REMOVAL FROM STORAGE
- 115 TAKING CARE OF THE UNEXPECTED
- **116 SPECIFICATIONS**
- **120 CATALYTIC CONVERTER**