
Tread Wear

Replace types immediately when the wear indicator appears at on the type.



(1) Wear indicator(2) Wear indicator location mark