

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
*	VALVE CLEARANCE	I	I	44
*	CAM CHAIN TENSIONER	A	A	52
*	CARBURETOR	I	I	39
	FUEL LINE	I: (EVERY YEAR)		—
*	FUEL STRAINER	C: (EVERY YEAR)		40
	THROTTLE OPERATION	I	I	50
	DRIVE CHAIN	I	I	51
*	FRONT & REAR BRAKE SHOES	I: (EVERY YEAR)		—
	FRONT & REAR BRAKE SYSTEM	I	I	47
*	CLUTCH	A	A	46
*	SPARK ARRESTER		C	55
	ALL NUTS, BOLTS, FASTENERS	I	I	—
	LIGHTING EQUIPMENT	I	I	—
	TIRES	I	I	18
*	STEERING HEAD BEARING	A: (EVERY YEAR)		—