


## STARTING THE ENGINE

### WARNING

- \* *Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas.*
- \* *Do not try to start the engine with the transmission in gear. You may injure yourself or damage the vehicle.*




(1) Vent lever

(2) Fuel valve

### Preparation

1. Select a level surface and lock the parking brake (page 10) before starting the engine.
2. Turn the fuel cap vent lever (1) and fuel valve (2) to ON.
3. Make sure the engine stop switch (3) is at RUN.
4. Make sure that the transmission is in neutral by lifting the shift lever and checking that the neutral indicator (4) is at N.
5. Make sure the Posi-Torque Speed Range and Reverse Selector lever is in the H or L position.



(3) Engine stop switch

(4) Neutral indicator