## munununununununun OPERATION munununununununununun

## PRE-RIDE INSPECTION

## WARNING

\* If the Pre-ride Inspection is not performed, serious damage or an accident may result.

Inspect your ATC200S every day before you start the engine. The items listed here will only take a few minutes to check and in the long run, can save time, expense, and possibly your life.

- 1. Engine oil level add engine oil if required (page 13). Check for leaks.
- 2. Fuel level fill the fuel tank when necessary (page 12). Check for leaks.
- 3. Brakes check operation; Adjust free play if necessary (page 45-47).
- 4. Tires check condition and pressure (page 15).
- 5. Drive chain check condition and slack (page 49). Adjust and lubricate if necessary.
- 6. Throttle check for smooth opening and closing in all steering positions (page 48).
- 7. Headlight switch check for proper function (page 7.)

- 8. Ignition switch check for proper function (page 7).
- Nuts, Bolts, Fasteners check wheels to see that axle nuts are tightened and secured by cotter pins. Check the security of all other nuts, bolts and fasteners.

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.