SERIAL NUMBERS


The frame and engine serial numbers are required by your dealer when ordering replacement parts. Record the numbers here for your reference. The frame serial number (1) is stamped on the right side of the steering head. The engine serial number (2) is stamped on the right crankcase.

FRAME	NO		
NAME	INO.		

ENGINE NO. ______



(1) Frame serial number



(2) Engine serial number