


SERIAL NUMBERS

The frame and engine serial numbers are required by your dealer when ordering replacement parts. Record the numbers here for your reference.


The frame serial number (1) is stamped on the right side of the steering head. The engine serial number (2) is stamped on the right crankcase.

FRAME NO. _____

ENGINE NO. _____



(1) Frame serial number



(2) Engine serial number