

Starter Valve

The knob (1) is on the right side of the carburetor. Raising the knob (A) will deliver a rich mixture for starting the engine when cold. Lower the knob (B) as the engine attains normal operating temperature.



(1) Starter valve
(A) Raise

(B) Lower