


STARTING THE ENGINE

WARNING

- * *Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas.*
- * *Do not try to start the engine with the transmission in gear. You may injure yourself or damage the vehicle.*



(1) Fuel valve

Preparation

Select a level surface and set the parking brake before starting the engine.

Starting Procedure

Cold engine starting

1. Turn the fuel valve (1) ON.
2. Move the ignition switch (2) to RUN.
3. Make sure that the transmission is in neutral.



(2) Ignition switch