

CONTENTS

SERIAL NUMBER LOCATIONS.....	4	PRE-RIDING INSPECTION	15
NOMENCLATURE	5	STARTING THE ENGINE	16
OPERATING INSTRUCTIONS	7	BREAK-IN PROCEDURE	17
Ignition Switch.....	7	RIDING	18
Rear Brake Lever	7	PARKING	18
Gear Change Pedal	8	STORAGE	18
Choke Handle	9	MAINTENANCE	19
Fuel Valve.....	9	Maintenance Schedule	19
Fuel Tank and Fuel Tank Cap	10	Tool Kit.....	23
Fuel Drain	11	MAINTENANCE OPERATIONS	23
Oil Recommendation	12	Engine Oil Level	23
Viscosity	12	Engine Oil Change	24
Engine Oil Level	13	Brake Adjustment	25
Throttle Lever	13	Drive Chain Adjustment	26
Tires	14	Drive Chain Lubrication	27