


ENGINE OIL LEVEL


To check the oil level, place the ATC on level ground and unscrew the dipstick ①. Wipe it dry and reinsert the dipstick in the oil filler hole; do not screw it in. Withdraw the dipstick again and check the oil level. The oil should be between the upper ② and lower ③ marks on the dipstick.



- ① Dipstick
- ② Upper oil level mark
- ③ Lower oil level mark

THROTTLE LEVER

The throttle lever ① is on the right handlebar grip and is operated by the rider's thumb. Pressing the lever forward opens the throttle. When the lever is released, spring tension closes the throttle automatically.



- ① Throttle lever